


STEM BOT Pro Kit Building Guide: How to Build the STEM BOT

The STEM BOT Pro Kit allows students to explore the possibilities of STEM and mobile robotics in various applications from basic to advanced concepts. This kit is available at <https://www.studica.com/studica-robotics-brand/stem-bot-pro-kit>.

These build instructions will walk you through the steps of building the STEM BOT. This is example of what the completed project will look like.







Table of Contents:

- STEM-BOT Build Instructions – Pages 3 - 9
 - Frame Assembly – 3
 - Back Wheels Assembly – 4, 5
 - Front Wheels & Battery Mount Assembly – 5, 6
 - Base Plate & Electronics Assembly – 7, 8
 - Wiring Guide – 9
 - Software Setup for Programming your robot – Page 10
 - Programming your STEM BOT – Pages 10 - 12
 - Configuring the project for VMXpi – 10, 11
 - Deploying Code – 11, 12
 - Adding Vendor Libraries - 12
- STEM BOT Parts List – Pages 12 - 18
 - 3D CAD files for all parts are available at www.studica.com/studica-robotics-resources
 - About the VMX Robotics Controller – Pages 19 - 20
 - Helpful Resources: Example of Code used for VMX - 19
 - Troubleshooting for VMX: Updating Firmware - 19
 - VMX: Map of Ports and Inputs - 20
 - About the Titan Quad Motor Controller – Pages 21 - 22
 - Titan: Map of Ports and Inputs – 21, 22
 - About the Maverick DC Motors – Page 23



STEM BOT Build Instructions:

This is a step-by-step guide for assembling the STEM-BOT along with an example of programming a two-wheel drive with the VMX. The example code is found here: <https://github.com/studica/WorldSkills-Example-Projects/tree/main/TwoWheelDrive> in both Java and C++. In Java it is contained in the src/main folder.

Frame Assembly:

Step 1: Attach the End Piece Plates to the ends of both 192mm U-Channels using the M3 x 10mm Button Head Cap Screws

Step 2: Attach the End Piece Plates of the 192mm U-Channels to the 432mm U-Channels using 4 M3 x 10mm Socket Head Cap Screws each.

Step 3: Place 4 Rubber U-Channel Bumpers to each end of the 432mm U-Channels



Step 4: Attach the Maverick DC Motor to the Motor Mount Plate using 6 M3 x 10mm Button Head Cap Screws:

Step 5: Attach 1 30 Tooth Bevel Gear onto the shaft of the Maverick Motors (Do not tighten set screws)



Back Wheels Assembly:

Step 6: Attach the motors to the Frame by having the recess into 432mm U-Channels and using the M3 x 12mm Socket Head Cap Screws (Repeat for other side of frame).

Step 7: Place 14mm Bearings onto the 14mm hole patterns of the 432mm U-Channel that are perpendicular to the end of the Maverick Motor's shaft (Repeat for other side of frame).



Step 8: Insert the 6mm x 96mm D-Shaft through the bearings as well as a 30 Tooth Bevel Gear. This gear as well as the gear mounted on the Maverick Motor shaft should both be positioned so that they mesh well with one another, once they do, tighten the gears to their shafts with their set screws.

Step 9: Attach a 6mm D-Shaft Collar Clamp on one end of the 6mm x 96mm D-Shaft with a 1mm Thick Shaft Spacer between the collar and bearing.

Step 10: Place two 5mm Thick Shaft Spacers then one Clamping Shaft Hub-v2 onto the 6mm x 96mm D-Shaft and secure the shaft hub using the set screws.


Step 11: Use 4 M3 x 12mm Socket Head Cap Screws to Attach the 100mm Drive Wheel to the Clamping Shaft Hub (repeat for other side of frame)




Front Wheels & Battery Mount Assembly:

Step 12: Stack two 288mm x 40mm Flat Brackets on top of one another and attach them to the frame using four M3 x 30mm Screws and four Kep Nuts on each side.

Step 13: Attach two 25mm Male to Female Standoffs to each Batter Clip with two M3 x 10mm Socket Head Cap Screws. Then secure the Battery Clips to the 288mm x 40mm Flat Brackets




Step 14: The 100mm Omni Wheel comes with its own shaft hub. Attach a 6mm x 96mm D-Shaft into the shaft hub and tighten with the set screws. Once tightened, screw the Hub onto the Omni-Wheel (repeat for other side of frame)



Step 15: Place two 14mm OD Bearings onto each side of the hole patterns of the 432mm U-Channels (Repeat for other side of frame)

Step 16: Insert the Omni Wheel Shaft through the bearings with a 1mm Thick Shaft Spacer between the bearing and shaft hub. (Repeat for other side of frame)


Step 17: Attach a Collar Clamp to the opposite end of the D-Shaft with a 1mm Thick Spacer between the clamp and U-Channel and secure by tightening the set screw. (Repeat for other side of frame)



Base Plate & Electronics Assembly:


Step 18: Secure the Titan Quad Motor Controller to the Base Plate using 4 M3 x 30mm Socket Head Cap Screws and 4 M3 Kep Nuts”.

Step 19: Secure the VMX Robotics Controller to the Same Base Plate using 4 M3 x 30mm Socket Head Cap Screws and 4 M3 Kep Nuts




Important: Refer to the Wiring Guide on page 9 before completing assembly.

Step 20: Align the Base Plate with the VMX and Titan so that the Titan is towards the back of the robot frame and the hole pattern aligns with the back 192mm U-Channel and the 432mm U-Channels. When aligned properly, screw 2 M3 x 12mm through the base plate and robot frame to the Motor Mount Plate





Studica ROBOTICS

Step 21: Attach the Base Plate to the frame of the robot by screwing 4 96mm T-Slot Extrusions to the frame and baseplate using 4 M3 x 12mm Socket Head Cap Screws for each extrusion. Then 2 M3 x 12mm Socket Head Cap Screws



Step 22: Attach another Base Plate to the extrusions using four M3 x 12mm Socket Head Cap Screws





Wiring Guide

The Titan Wire Pack contains the required cables and wires to power the VMX and provide communication between the Titan and VMX. The two devices communicate with one another via CAN (Control-Area-Network) Bus Cable (Green Low, Yellow High)

Step 23: Connect the power cable to the power output port on the Titan to the power port of the VMX. This allows for the Titan to distribute power to the VMX.


Step 24: Connect the Powerpole 45 Extension cable to the power input port of the Titan.


Step 25: Connect the green cable to the Green (L) port of the Titan and L (GRN) port of the VMX and connect the yellow cable to the Yellow (H) port of the Titan and the H(YEL) port of the VMX.

Step 26: Connect the Left Motor and Encoder cables to the M0 port. Then connect the Right Motor cables and encoder cables to the M2 port.



Step 27: Place the Battery in between the battery clips and connect it to the Powerpole 45 Extension Cable.






Software Setup for Programming your Robot

Installing WPILib & VS Code:

To install WPILib, access our international website here: <https://www.studica.co/resources-4> and click on the “Download all the Studica Robotics Resources” link:



Find the appropriate operating system you are using (Windows, macOS, Linux) and install the zip files for VSCode and WPILib. The installation files can be alternatively found through the WorldSkills Technical Documentation & Software resources on Studica’s International website: <https://www.studica.co/resources-4>


For Windows 11: FRC Driver Station

For Windows 11 users, FRC Driver Station is the interface software used to access and communicate with the robot. To download, click here to access the FRC Game Tools components: <https://www.ni.com/en/support/downloads/drivers/download.frc-game-tools.html#500107> and download the latest version.

Programming your STEM BOT

Configuring the project for VMXpi


The VMXpi Extension must be installed so the VMX can be the deployment target. In the extensions tab, click on the search bar and enter “VMX-pi”:



Install this extension and it should appear next to the WPILib logo.


Deploying Code:

To deploy your code to the VMX, click on the VMX-Pi logo:




VMX-Pi logo

The following commands will pop up:



Clicking the “Change the deploy target to VMX-Pi (from RoboRio)” will update the build.gradle file to update the target as the VMXpi and cache any missing libraries.



To deploy the code to the VMX, click on the WPILib Logo and click on the command “Deploy Robot Code”,

Adding Vendor Libraries



The vendor libraries supported on the VMXpi are below. To install these libraries on VS Code, open the command palette using Ctrl+Shift+P or F1. Type into the command palette “**Manage Vendor Libraries**”, Select **Install new libraries(online)**, copy and paste the links into the command palette and press Enter.

NavX Library: <https://dev.studica.com/releases/2023/NavX.json>






Titan Library: <http://dev.studica.com/releases/2020/Studica.json>

STEM BOT Parts List






3D CAD files for all parts are available at www.studica.com/studica-robotics-resources

Name	Part #	Qty	Image
Electronics & Accessories			
12V 3,000 mAh NiMH Battery Pack, PP45	70018	1	
NiMH Battery Pack Charger – PP45	70019	1	

Titan Quad Motor Controller	70152	1	
Titan Cable Pack	70162	1	
VMX Robotics Controller	70176	1	
Maverick 12V DC Gear Motor w/Encoder	75001	2	
U-Channel			
432mm U-Channel	76010	2	


192mm U-Channel	76015	2	
Flat Brackets			
288mm x 40mm Flat Bracket (2 pack)	76061-2	1	
Robot Base Plate	74001	2	
Extrusions			
96mm T-Slot Extrusion	76127		
Irregular Brackets			
Battery Clip (2 pack)	76088-2	1	
Mounting Plates			

Motor Mount Plate	76140	2	
End Piece Plate (2 pack)	76143-2	2	
Axles			
6mm x 96mm D-Shaft	76161-6	1	
Standoffs			
25mm Male to Female Standoff	76184-12	1	
Screws and Nuts			
M3 x 10mm Socket Head Cap Screw	76201-100	1	

M3 x 12mm Socket Head Cap Screw	76202-100	1	
M3 x 10mm Button Head Cap Screw	76203-50	1	
M3 x 30mm Socket Head Cap Screw	76206-50	1	
M3 Kep Nut (100 pack)	76204-100	1	
Gears			
30 Tooth Bevel Gear	76219-2	2	
Wheels			

100mm Omni Wheel	76260	2	
100mm Drive Wheel	76262	2	
Bushings, Bearings, Collars, & Spacers			
Clamping Shaft Hub-v2	76280	4	
Collar Clamp	76320	4	
14mm Flange Bearing	76302-12	1	

Shaft Spacer 1mm, Nylon (24 pack)	76305-24	1	
Shaft Spacer 5mm, Nylon (12 pack)	76307-12	1	
Rubber Grommet	76504-10	1	
U-Channel Bumper (4 pack)	76505-4	1	



About the VMX Robotics Controller

As the “brain” of a robot, the VMX Robotics Controller is a powerful, versatile Linux-based robot controller that offers compatibility with programming languages including Java, C++, Python, and LabVIEW, along with support for ROS. Integrated with the NavX-IMU and combined with the Titan Quad Motor Controller, the VMX acts as the powerful “brain” of your robot. Capable of programming for both tele-operated and autonomous controls. It also houses an integrated NavX IMU (Inertial-Measurement-Unit) for advanced movement performance in tele-op and autonomous driving.



Helpful Resources: Example of Code used for the VMX

This guide will go over an example project from Studica Robotics github, using the VMX. The example code can be found here: <https://github.com/studica>, in the WorldSkills-Example-Projects repository under the Popular Repositories.


Troubleshooting for VMX: Updating Firmware

Certain cases may require the firmware to be updated for the VMX to improve functionality or fix any bugs. To do so, use the following instructions on our WorldSkills resources page:


<https://docs.wsr.studica.com/en/latest/docs/VMX/update.html>

A firmware update should be performed in case there

VMX: Map of Ports and Inputs




Connector Block	Connector Type	Location on VMX
Flex DIO Header	3-pin PWM-style	Left-side Top
High Current DIO Header	3-pin PWM-style	Left-side mid
Analog Input Header	3-pin PWM-style	Left-side bottom
Comm DIO Connectors	4-pin JST GH	Bottom-left
Flex DIO Connectors	4-pin JST GH	Bottom-middle
CAN Connector	2-wire Weidmuller	Bottom-right




About Titan Quad Motor Controller:

The Titan Quad Motor Controller is a 4 channel CAN-based motor controller. Combined with the VMX, the Titan acts the Power Distribution Panel (PDP) for your robot, primarily for the VMX.




Titan: Map of Ports and Inputs

1. Power input. Input requires a 12VDC battery, and two ports are available connected in parallel. Both ports can be used for increasing the capacity or as a battery in, battery out.
2. Power output. Outputs 12VDC out to other devices such as, VMXpi or Servo Power Block.
3. Voltage indicators. There is a reverse power indicator (red) that will light up if the voltage is connected in reverse. The other two indicators display the voltage rails 5V and 3.3V.



4. Fusebox. Before voltage can be applied to the motors or power outputs (2), an appropriate fuse must be inserted into the box. Motors take 20A fuses, and power outputs take 5 - 15A fuses.
5. RGB Status Light.
6. DFU USB - used to communicate with the computer for updates and configuration.
7. CAN-BUS Input - High side (yellow) and Low side (green) inputs.
8. M1 - Motor 1 output.
9. M0 - Motor 0 output.
10. M3 - Motor 3 output.
11. M2 - Motor 2 output.
12. Boot - used only when an error occurs, and Titan cannot communicate with the computer and needs a firmware upgrade.
13. NeoPixel - addressable LED output
14. DotStar - addressable LED output
15. Pin 13/ L for LED microcontroller
16. RX/TX - LEDs for microcontroller
17. LED i2c - com port for microcontroller
18. LED USB - used to communicate with the computer for uploading code.
19. Encoder port - Quadrature encoder input
20. Limit H - High limit switch input. (Limits are pulled high and use hardware debouncing)
21. Limit L - Low limit switch input. (Limits are pulled high and use hardware debouncing)



About the Maverick DC Motor:

The Studica Robotics Maverick 12V DC Gear Motor 61:1 w/Encoder is an ideal robot motor designed for strength to endure competitions, providing a stall torque of 708 oz-in.



Specifications:

Function	Min	Nom	Max
Input Voltage	-	12VDC	-
Gear Ratio	-	61:1	-
No Load RPM	88	100	112
No Load Current	-	600mA	-
Rated Speed	68	80	92
Rated Current	-	-	2.2A
Rated Torque	-	139 oz-in	-
Stall Current	-	-	11A
Stall Torque	708 oz-in	-	-
Direction	-	CW	-
Encoder Voltage	4	-	5
Encoder Current	-	6mA	-
Encoder CPR	-	6	-

Output Counts per Revolution of Output Shaft (cpr) 1,464